

Guide for replacement of FLXE Big can shelf belt

更换配件指导---- FLXE 大罐搅拌层皮带



Before replacement, must unplug of mixing machine.

先断开电源插头，再开始更换配件

For safety, worker must wear gloves.

为确保安全，请操作人员全程佩戴手套。

1st step: Open the cover of shaft, take the shaft kit as following pictures

第一步：如图示，拆卸传动轴护板，拆卸传动轴，打开搅拌层盖板。



2nd step: Loose the tension pulley blow the shelf at right, take the broken belt apart,

第二步：拧松搅拌层右侧底部张紧轮，拆卸故障皮带；




Guide for replacement of FLXE Big can shelf belt

更换配件指导---- FLXE 大罐搅拌层皮带



3rd step: Install the new belt of shelf, pay attention the belt goes around the tension pulley

第三步: 安装搅拌层新皮带，如图所示：注意皮带绕行张紧轮方式。



4th step: Install the cover of shelf, the transmission shaft, and the cover of shaft.

第四步: 复位搅拌层盖板，复位轴及轴护板。

