

Guide for replacement of FLXE Motor belt

更换配件指导----FLXE 电机皮带



Before replacement, must unplug of mixing machine.

先断开电源插头，再开始更换配件

For safety, worker must wear gloves.

为确保安全，请操作人员全程佩戴手套。

1st step: Take the control box apart, take the motor kit apart, take the broken belt apart.

第一步：拆卸控制盒，拆卸电机及电机托盘，使电机托盘底部暴露在操作台面，
拆卸故障皮带；



2nd step: Install the new belt and adjustment tightness of belt.

第二步：安装新皮带，并调整皮带松紧度(如图示)；





Guide for replacement of belt of FLXE motor kit

更换配件指导----FLXE 电机皮带



3rd step: Install the motor kit with mixing machine, install the transmission shaft and the cover of shaft, install the control box.

第三步：组装电机组件至搅拌机正确位置，安装底层传动轴总成，安装底层轴护板；安装控制盒入位。

